




TAMPING RAMMER

MTX-50E

MTX-60E/FE/HDR

MTX-70E/FE/HDR

MTX-80HDR



## INSTRUCTION MANUAL

en

We thank you for selecting Mikasa Tamping Rammer.  
For your safe and proper operation, please read this manual and  
be always sure to keep it ready for reference.




<http://www.mikasas.com>

Contents of "Declaration of Conformity"  
Please refer the EC DECLARATION OF CONFORMITY  
in this manual as well.

302-02818



## 1) DECLARATION OF CONFORMITY

2) Manufacturer's name and address.		Mikasa Sangyo Co., Ltd. 1-4-3, Kanda-Sarugakucho, Chiyoda-ku, Tokyo, 101-0064, JAPAN				
3) Name and address of the person who keeps the technical documentation.		Yoshiharu Nishimaki, engineer R&D Division, Mikasa Sangyo Co., Ltd. Shiraoka-city, Saitama, Japan				
4) Type: <b>Vibratory Rammers</b>						
5) model	MTX-50 HD/E	MTX-60 HD/E/FE	MTX-70 HD/E/FE	MTX-60HDR	MTX-70HDR	MTX-80HDR
6) Equipment item number	251580, 251581	251601, 251603, 251605, 251607, 251640, 251670, 251671, 251680, 251681 251685 251689, 251690	251614, 251616, 251619, 251641, 251672, 251673, 251682, 251683, 251687, 251692	251740	251618, 251741	251625, 251742 251728
7) Serial number	For serial number, please refer it on front page.					
8) power source cont. output <max.output>	Honda GX100 1.7kW <2.1kW>	Honda GX100 1.7kW <2.1kW>	Honda GX100 1.7kW <2.1kW>	Honda GXR120 2.1kW <2.7kW>	Honda GXR120 2.1kW <2.7kW>	Honda GXR120 2.1kW <2.7kW>
9) Measured sound power level(dB)	102	103	104	100	105	104
10) Guaranteed sound power level(dB)	107	107	107	107	106	107
11) Max. Sound pressure level(dB)	92	92	94	91	93	93
12) Conformity assessment according to Annex:	VIII (Full Quality Assurance procedure)					
13) Name and address of the Notified Body	Société Nationale de Certification et d'Homologation (SNCH) 11, route de Luxembourg L-5230 Sandweiler LUXEMBOURG					
14) Related Directive	Directive <b>2000/14/EC</b> and, to be followed by Directive <b>2005/88/EC</b> , relating to the noise emission in the environment by equipment for use outdoors.					
15) Declaration	The equipment referred in this document, fulfills with all the requirements of Directive 2000/14/EC					
16) Other related Community Directives	<b>2006/42/EC, 2005/88/EC, 2014/30/EU, 2002/88/EC(2004/26/EC)</b> EN500-1, EN500-4					
17) EC Conformity Certificate No:	SNCH*2000/14*2005/88*0472*05					
18) Place and date of the declaration	Tokyo, Japan August, 2019 Signed by:  Keiichi YOSHIDA Director, R&D Division Mikasa Sangyo Co., Ltd.					

### Hand-Arm Vibration Level

MODEL	Ahv (m/sec <sup>2</sup> )	Remarks
MTX-50HD/E	4.9	Vibration Level is in comply with EU Directive2002/44/EC and the value is shown as 3 axis min. vibration level.
MTX-60HD/E/FE	5.2	
MTX-70HD/E/FE	5.6	
MTX-60HDR	5.6	The above values are subject to change in case that the machine is modified or/and the required regulations change.
MTX-70HDR	4.9	
MTX-80HDR	4.2	

## Table of contents

1. INTRODUCTION .....	1
2. APPLICATION, STRUCTURE AND POWER TRANSMISSION .....	1
3. WARNING SIGNS .....	2
4. CAUTIONS FOR SAFETY.....	2
4.1 General Cautions	2
4.2 Precautions When Adding Fuel	3
4.3 Precautions About Where To Use The Machine	3
4.4 Precautions Before Starting Work	3
4.5 Precautions While Lifting	4
4.6 Transportation And Storage Precautions	4
4.7 Maintenance Precautions	5
4.8 Label Position	6
4.9 Label List	7
4.10 Descriptions Of The Symbols On The Warning Decals	7
5. SPECIFICATION.....	8
5.1 Body	8
5.2 Engine	9
6. APPEARANCE .....	10
6.1 Appearance Dimension	10
6.2 Control Unit Positions And Names	11
7. INSPECTION BEFORE OPERATION .....	12
8. OPERATION .....	13
8.1 Starting	13
8.2 Operation	14
9. STOPPING THE MACHINE.....	15
10. MAINTENANCE AND STORAGE.....	15
11. PERIODIC CHECKS AND ADJUSTMENTS.....	16
11.1 Table Of Scheduled Checks	16
11.2 Inspection And Maintenance Work Contents	16
12. TROUBLE SHOOTING.....	18

## 1. INTRODUCTION

- This instruction manual describes the proper methods for using the tamping rammer, as well as simple checks and maintenance. Be sure to read this instruction manual before using the rammer, in order to get full use of the excellent performance of this machine, to improve your operation and to perform work effectively.
- After reading this manual, store it in a handy location for easy reference.
- For details about the engine in this machine, see the separate instruction manual for the engine.
- For inquiries about repair parts, parts lists, service manuals, and repair of the machine, please contact the shop where you purchased it, or the Mikasa Website. In addition, parts lists are available on the MIKASA website at: <http://www.mikasas.com/english/>

The illustrations in this manual might slightly differ in part from the machine you actually purchased due to design changes.

## 2. APPLICATION, STRUCTURE AND POWER TRANSMISSION

### Application

Though compact and lightweight, this rammer creates a strong impact and you may expect a large tamping effect on the ground.

It will compact nearly all types of soil, except soft soil that contains too much moisture.

Use this rammer to tamp the ground for creating roads, embankments, and to prepare the surface to support buildings. It can also be used when burying gas or water lines, and electric cables.

### Warning About Incorrect Applications And Techniques

Do not use this machine on ground that is harder than the machine can handle, or for driving pilings or tamping rock beds. Furthermore, use of the machine on sloping ground such as the side of an embankment, may make the machine unstable and can cause an accident. It can also result in premature machine wear due to uneven loads on the machine.

Use the machine with confidence for tamping earth and sand, soil, sand, gravel, and asphalt. Do not use the machine for other type of jobs.

### Structure

The upper section of the machine functions as a weight and consists of an engine section, a gear reducer section, and reciprocating section. It also accommodates the handle and the fuel tank sections, which are connected by rubber dampers.

The lower section of the machine which hits the ground, consists of a spring case to engage sliding motion, a sloping section to allow the machine to tilt toward the front, bellows to cover the foot, a sliding section, and a protective sleeve.


### Power Transmission






Power is provided by an air-cooled, 4-cycle, single-cylinder diesel engine. The output end of the engine crankshaft is equipped with a centrifugal clutch.

As the engine speed increases, the centrifugal clutch expands and a pinion gear that is a part of the clutch drum engages a gear in the crank shaft on the main frame. The engine speed is decreased in order to produce the required force for tamping.

The rotating motion of the main frame crankshaft is converted to a reciprocating motion through a connecting rod. This reciprocating motion causes the foot to go up and down through a strong coil spring. The weight of the main body and the strong force from the engine compress the spring and the foot moves up and down, striking the ground forcefully.

### 3. WARNING SIGNS

The triangle shaped  marks used in this manual and on the decals stuck on the machine indicate common hazards. Be sure to read and observe the cautions described.

 <b>Warning labels indicating hazards to humans and to equipment.</b>	
 <b>DANGER</b>	Denotes an extreme hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, is likely to result in serious injury or death.
 <b>WARNING</b>	Denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in serious injury or death.
 <b>CAUTION</b>	Denotes a hazard. It calls attention to a procedure, practice, condition or the like, which, if not correctly performed or adhered to, could result in injury to people and may damage or destroy the product.
<b>CAUTION</b> (without at  )	Failure to follow the instructions may result in damage to property.

### 4. CAUTIONS FOR SAFETY

#### 4.1 General Cautions

##### **WARNING**

- Do not work with this machine, when
  - you are tired or sick and not feeling well.
  - you have taken medicine or drug.
  - you have had a drink alcohol.



##### **CAUTION**

- Please read the operation manual well and work safely by using the machine properly.
- For handling of the engine, please read to the attached engine operation manual.
- Please understand of the structure of this machine well.
- Make sure to do the inspection and check the machine conditions before starting operation.
- Please use protective equipment such as helmet, protective shoes, protective gloves, etc., and wear appropriate work clothes for making your work safe.
- Always wear noise protection equipment such as ear muffs or ear plugs and protective eyeglasses.
- The decals shown operation method, warning and etc. stuck on the machine are very important for your safety. Clean the machine so that the decals can be read easily. If it is difficult to read the decals, please replace with new ones.
- It is dangerous if children touch the machine. Please be careful about storage location and storage method for the machine.
- Stop the engine before maintenance work.
- We are not responsible for any accidents occurred due to the fixing without using genuine parts (foot and etc.) and equipment modifications.



## 4.2 Precautions When Adding Fuel

### DANGER

- When adding fuel.
  - Be sure to work in a well ventilated location.
  - Be sure to work in a clear and flat location without any combustibles nearby.
  - Be sure to stop the engine and wait until it has cooled down.
  - Do not use any flames (smoking and etc.) while adding fuel.
  - Do not overfill tank. If you spill some fuel, wipe it all up.
  - Tighten the tank cap securely after adding fuel.



## 4.3 Precautions About Where To Use The Machine

### DANGER


- Do not run the engine in any enclosed or narrow area, such as indoors or in a tunnel. Engine exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause death if inhaled.
- Do not operate the machine near flames.



## 4.4 Precautions Before Starting Work

### CAUTION

- If you use the machine for a long time, be careful to watch for signs of vibration syndrome. Since this machine vibrates, work for a long time may have a negative effect on your body. Take sufficient breaks while working.
- Before starting to operate the machine, check the safety for people around and obstacles nearby.
- When starting the engine, the rammer may jump suddenly. Hold the handle firmly and then pull the recoil starter.
- Always be careful around ground condition at job site. Operate the rammer in stable position and balance.
- Keep your foot away from the foot of the rammer during work. The foot of the rammer may crush your foot.
- Do not touch the muffler, muffler cover and main body of the engine during work or soon after work, because they are very hot.
- If you find trouble or damage of the machine during work, stop work immediately. Before leaving or moving the machine, be sure to stop the engine.
- When lifting the rammer with the handle, be careful not to pinch your fingers between the handle and main body.
- Push down the rear end of the handle as shown in the left figure (A) and check that there is no damage on the shock absorbers. If it found the damaged shock absorbers, replace them with new ones by left and right set.



**⚠ DANGER**


- Take the utmost care not to fall over the rammer during work, stored or stopped. Tie down the rammer with cable (wire or rope) when stopped or stored so that it cannot fall.
- If the rammer falls over when children are nearby, they may have a serious accident.
- If the foot of the rammer is worn, the rammer will be especially unstable.
- If the foot of the rammer is severe worn, replace it with new one.
- If the rammer falls over during work, it will move to forward due to kicking motion of the foot while falling over. And if the ground is solid, the rammer will move quickly so it is very dangerous. After ensuring that the operator and people around are safe, move the throttle lever to the engine stop position and make sure the rammer stops.
- Take careful note of safe especially when working on the public road, because a serious accident can occur easily.



**4.5 Precautions While Lifting**

**⚠ DANGER**


- Before lifting the machine, make sure that there is no damage to parts on the machine (especially the shock absorber and the hook), loosening or missing of the bolt, and the machine must be in a safe condition.
- Stop the engine before lifting the machine.
- Use adequate lifting cable (wire or rope) of sufficient strength for support to the machine.
- Do not lift it higher than necessary for safety.
- Do not use a damaged lifting cable.
- Use one point lifting hook for lifting the machine and lift straight upwards. Do not use any other points (such as the handle) for lifting.
- Never lift or lower the machine rapidly with hydraulic excavator.
- Never allow any person or animal to stand underneath the machine while lifting.
- Be careful not to an accident when using any lifting equipment. Before using the lifting equipment, make sure that there is no trouble or damage.



**4.6 Transportation And Storage Precautions**

**⚠ DANGER**

- Stop the engine before transporting or storing the machine.
- After the engine and main body have cooled down enough, transport or store the machine.
- Drain any fuel before transporting or storing the machine.
- Maintain upright position of this rammer on a level floor during transporting or storing. If it has to lay down the rammer of necessity, drain the fuel, tighten the tank cap, and then lay down it with muffler side down. After it lies down, make sure that there are no oil or fuel leaks.
- Tie down the rammer with cable (wire or rope) so that it cannot move or fall over.
- When lifting the rammer with the handle, be careful not to pinch your fingers between the handle and main body.
- When transporting the rammer, use MC-1A of Mikasa Carry or similar product.



## 4.7 Maintenance Precautions

### **WARNING**

- Ensure safety for maintenance. It needs appropriate maintenance for keeping the machine performance. Keep the machine in good condition with attention to the machine's condition always.


### **CAUTION**

- Be sure to stop the engine before maintenance of the machine.
- Do not touch the muffler, muffler cover and main body of the engine until they have cooled down enough to prevent burn.
- Do not touch the lubrication oil and engine oil until they have cooled down enough to prevent burn.
- When maintenance of the machine with disassembling, be sure to refer the service manual and always work safely.
- After maintenance of the machine, check that the parts are assembled properly and machine conditions for safety.






## 4.8 Label Position



## 4.9 Label List

No.	Part No.	Part Name	Label No.	Remarks
1	9202-15440	DECAL,OPERATION	NPA-1544	
2	9202-12460	DECAL,AIR CLERNER	NPA-1246	
3	9202-12470	DECAL,LEVER OPERATION	NPA-1247	
4	9202-12490	DECAL,MAX SPEED 4100	NPA-1249	
5	9202-12480	DECAL,MACHINE STOP	NPA-1248	
6	9202-10310	DECAL,EC NOISE REQ.LWA107	NPA-1031	
7	9202-12840	DECAL,CHOKE OPERATION	NPA-1284	
8	9202-12540	QUICK MANUAL	NPA-1254	
11	_____	PLATE,SERIAL NO./MTX-50	_____	MTX-50E
11	_____	PLATE,SERIAL NO./MTX-60	_____	MTX-60E/60FE/HDR
11	_____	PLATE,SERIAL NO./MTX-70	_____	MTX-70E/70FE/HDR
11	_____	PLATE,SERIAL NO./MTX-80	_____	MTX-80HDR

## 4.10 Descriptions Of The Symbols On The Warning Decals



- A. Read the instruction manual carefully  
 B. Don't fill the fuel tank while the engine is running or hot.  
 C. Don't operate the machine in a poorly ventilated area.  
 D. Fire hazard  
 E. Danger: poisonous exhaust gas  
 F. Be careful not to get burned  
 G. Don't let your foot slip under the machine foot.  
 H. Lay the machine down carefully  
 I. Wear protective clothing, such as safety glasses.  
 J. Wear protective clothing, such as ear protectors.  
 K. Lift point.  
 L. Lifting with a forklift is prohibited  
 M. Lifting the machine by the engine guard is prohibited  
 N. Fuel specification (gasoline)



### Starting and running

- Slide the throttle lever to the idle position.
- Turn the choke lever to the "Closed" position.
- Pull the recoil starter handle.
- Turn the choke lever to the "Open" position.
- Slide the throttle lever to the operating position.



### Stopping

- After work, slide the throttle lever to the idle position.
- After the machine has cooled down a little, slide the throttle lever to the stop position.

<b>Mikasa</b>	
MODEL/MACHINE TYPE/ MODELL/MODELLO/MODELO	_____
SERIAL NO./N DE SERIE/ FABRI. NR./N. MATRICOLA/ N. MATRICOLA	_____
WEIGHT/POIDS TOTAL/ BETREIBSGEWICHT/ PESO. MAX./PESO OPERATIVO	_____ kg
OUTPUT/PUISS. MAXI/ LEISTUNG/POTENZA MASSIMA/ POTENCIA MAX	_____ kw
CE _____	Made in Japan
<small>MKASA SANGYO CO.,LTD 1-4-3,Shiragaki-cho,Chiyoda-ku,Tokyo,Japan</small>	

### Product number name plate

Product name, machine serial number, weight, engine output, and CE mark

## 5. SPECIFICATIONS

### 5.1 Body

Model		MTX-50E	MTX-60E/FE	MTX-60HDR
Dimensions	Overall height	1025		
	Overall width	mm	350	
	Overall length	713		
Plate Size	Length	mm	340	
	Width		265	
Fuel Tank Capacity		L	2.5	
Main Body Oil		API Service Categories SE or higher SAE 10W-30		
Oil Capacity		cc	350	650
Number of Blow		Hz/v.p.m	10.7~11.6/644~695	
Impact Force		kN/kgf	10.3/1,050	13.6/1,390
Jumping Stroke		mm	40~70	50~80
Operating weight		kg	60	64
Engine model		GX100RT		GX120RT

Model		MTX-70E/FE	MTX-70HDR	MTX-80HDR
Dimensions	Overall height	1027(70FE:1055)		1027
	Overall width	mm	350	
	Overall length	788(70FE:713)		788
Plate Size	Length	mm	340	
	Width		285	
Fuel Tank Capacity		L	2.5	
Main Body Oil		API Service Categories SE or higher SAE 10W-30		
Oil Capacity		cc	820	
Number of Blow		Hz/v.p.m	10.7~11.6/644~695	
Impact Force		kN/kgf	14.9/1,520	15.6/1,590
Jumping Stroke		mm	50~80	
Operating weight		kg	75	82
Engine model		GX100RT	GX120RT	


## 5.2 Engine

Model		Honda GX100RT
Type		Air-Cooled 4 Stroke, OHC Single cylinder gasoline engine.
Caburetor System		Diaphragm type / Flat type
Piston Displacement	cc	121
Max. Output <sup>※</sup>	kW(PS)/rpm	2.1 (***)/3600
Fuel		Unleaded gasoline
Engine Oil		Automobile Oil ; Class SE or higher
Oil Capacity	cc	280
Starting System		Recoil starter
Setting speed	min <sup>-1</sup> /rpm	3800 – 4100

Model		Honda GX120RT
Type		Air-Cooled 4 Stroke, OHC Single cylinder gasoline engine.
Caburetor System		Diaphragm type / Flat type
Piston Displacement	cc	121
Max. Output <sup>※</sup>	kW(PS)/rpm	2.7 (***)/3600
Fuel		Unleaded gasoline
Engine Oil		Automobile Oil ; Class SE or higher
Oil Capacity	cc	280
Starting System		Recoil starter
Setting speed	min <sup>-1</sup> /rpm	3800 – 4100


## 6. APPEARANCE

### 6.1 Appearance Dimensions



※ Specifications are subject to change without notice.

**6.2 Control Unit Positions And Names**



## 7. INSPECTION BEFORE OPERATION

### **⚠ WARNING**

- Check the machine while the engine is stopped. You may be caught in a rotating part and be seriously injured.
- Check the machine after it has cooled down. Since the muffler is very hot, you may be burned.



Inspection points	Inspection items
Appearance	Flaws, deformity, dirt
Air cleaner	Dirt, flaws, deformity
Bolts, nuts	Loose or missing
Handle	Flaws, deformity, cracks, breaks
Rubber damper	Flaws, deformity, cracks, breaks
Engine oil	Leaks, oil level, dirt
Main body oil	Leaks, oil level, dirt
Fuel tank	Leaks, fuel level, dirt
Fuel system	Leaks, wear, loose parts

It is extremely important that this section be read carefully before attempting to operate the rammer. Do not use your rammer until this section is thoroughly understood. Use 10W-30 engine oil rated SE or SF or better for the engine.

1. Clean each parts of the machine so that there is no mud or dirt on them.
2. Make sure that all bolts and nuts are not loosened. If they are loosened, retighten them to prevent an accident and trouble.
3. Replace any missing or damaged safety and operation decals.
4. Check the main body oil through the oil gauge on the protection sleeve on level ground. (Fig.1)




Fig.1




Fig.2

6. Fill the fuel tank with automobile gasoline fuel. (Fig.3)





Fig.3

5. Check the engine oil. For checking the engine oil level, move the engine to vertical position and check that the oil is filled at the oil inlet (280cc). (Fig.2)

## 8. OPERATION

### 8.1 Starting

1. Slide the throttle lever from the stop to the idling position (→). That opens the fuel cock and the engine electrical circuit is turned on automatically. (Fig.4-1)




#### **Diaphragm carburetor with Primer system**



Push the bulb at Primer Pump several times, which delivers fuel to the carburetor forcibly. (Fig.4-2)

#### Note


The one possible problem with Primer System is the fuel flooding in the carburetor because the bulb is pressed in excessive times.



2. Push the choke lever on the carburetor to the closed position. When it is cold, close the choke all the way. When it is hot, such as in the summer, or when the engine is already hot, open the choke a little or leave it fully open. If the engine cannot be started, open the choke a little so as not to flood the carburetor. (Fig.5-1, 5-2)



3. Hold the recoil starter handle and pull it a little. You will feel resistance. Then, pull it hard to turn the engine. Allow the starter rope to return slowly into the case before letting go of the handle. (Fig.6)



4. After the engine has started, open the choke lever gradually until it is wide open. Pay attention to the sound of the engine to guide you in the amount to open the choke. After the engine has started, be sure to warm up the engine at low speed for 3 to 5 minutes. During this time, check the machine for leaking fuel, abnormal sounds, or abnormal exhaust color or odor.



**⚠ WARNING**

When warming up, if in the semi-clutch in order not to be, **pay attention to engine speed.**


5. If the engine cannot be started after pulling the starter handle several times, remove the spark plug and see if it has a spark. If the plug is wet from fuel (due to flooding from the carburetor), or if it is stained, replace the plug or clean it thoroughly. While the plug is removed, pull the starter handle 2 to 3 times to discharge any fuel from the cylinder.

**8.2 OPERATION**

1. Shift the throttle lever from idling (👉) to the operating position (👈) (Fig. 7) and the tamping rammer will start up and down motions. Shifting the lever slowly will cause irregular operation and damage the clutch, springs, and foot.

**⚠ CAUTION**

If you start it's operating too quickly the engine may stop due to the operation of the carburetor.




2. After operation is started, adjust the throttle lever a little until the rammer tamps the soil correctly. When the engine is running within the specified rpm range, the rammer will be the most effective. If the engine runs too fast, the tamping force will not be increased. Instead, the spring resonance will decrease the tamping force and damage the machine.

**⚠ WARNING**


If the rammer is used on sloping ground, check the safety of the surroundings and be careful not to allow the machine to fall over.

3. In the cold season, the oil in the machine will be thicker, and the resistance of the components will be much larger, which may cause irregular motion. Shift the throttle lever from the operating to the idling position several times and allow it to warm up sufficiently before starting actual work.
4. The surface of the foot in contact with the ground is a metal sheet that has excellent wear resistance. However if you need to tamp ground that contains large stones (about the size of a fist), first put some fill soil over them so that the foot will tamp the ground evenly.
5. The machine body will advance as it jumps. If you want to move forward faster, push the handle a little forward to make the machine body lean a little forward.
6. To halt work, quickly slide the throttle lever from the operating position (👈) to the idling position (👉). Do not slide the throttle lever slowly (Fig.8).



## 9. STOPPING THE MACHINE

1. Slide the throttle lever from the operating position (↻) to the idling position (↻). Run the engine at low speed for 3 to 5 minutes to cool it down. Then slide the throttle lever from the idling position to the stop position. The engine will stop and the fuel cock is closed automatically. (Fig.9)
2. If the engine does not stop due to a problem with the switch or something similar, take the machine to a safe location and hold the throttle lever in the stop position. Let the machine run in idling and the engine will stop after a few minutes.



## 10. MAINTENANCE AND STORAGE

1. Wash off any dirt or mud on each part of the machine using fresh water.
2. After the engine and main body have cooled down, store the rammer on a level location. Secure the machine body so that it can not fall down. If you have to lay the machine down, close the fuel tank cap securely and tighten engine oil drain plug. After the engine and machine body have cooled down, lay the machine so that the carburetor is facing up. Once the machine has been laid down, make sure that there is no fuel or lubrication oil leaks. (If the fuel leaks, drain the fuel from the fuel tank.)
3. Put a cover on the machine body to prevent dirt landing on it. Store the machine in a location that is not exposed to direct sunlight and which has low humidity.
4. For prolonged storage
  - Slide the throttle lever to the stop position.
  - Drain any fuel and replace the lubrication oil. Apply grease to the lubrication points. Be sure to remove any fuel in the fuel hose, too.
  - Cover the air intake on the air cleaner and the exhaust outlet on the muffler.
  - Store the machine indoor. Do not leave it outside.

## 11. PERIODIC CHECKS AND ADJUSTMENTS

### ⚠ WARNING

- Check the machine while the engine is stopped. You may be caught in a rotating part and be seriously injured.
- Check the machine after it has cooled down. Since the muffler is very hot, you may be burned.



### 11.1 Table Of Scheduled Checks

How often?	Place to check	Item to check	Reference
Daily (before starting operation)	Appearance	Flaws, deformity, dirt	
	Air cleaner	Dirt, flaws, deformation	
	Bolts, nuts	Loose or missing parts	
	Handle	Flaws, deformity, cracks, breaks	
	Rubber damper	Flaws, deformity, cracks, breaks	
	Engine oil	Leaks, oil level, dirt	Engine oil
	Main body oil	Leaks, oil level, dirt	Engine oil
	Fuel tank	Leaks, fuel level, presence of dirt	Gasoline
	Fuel system	Leaks, wear, loose parts	
After first 20 hours	Engine oil	Replace once, after the first 20 hours	Engine oil
Every 50 hours	Spark plug	Clean, adjust gap	
	Engine oil	Replace	Engine oil
Every 80 to 100 hours	Air cleaner element Primary	Cleaning	Lamp kerosene Engine oil(25-30cc)
	Air cleaner element Secondary	Cleaning	Neutral detergent (water washing and dry)
Every 200 hours	Engine oil / Main body oil	Replace once, after the first 50 hours	Engine oil
Every 2 years	Fuel hose	Replace	
	Intake Pipe	Replace	

Regarding the check and maintenance of the engine in details, please refer to the attached engine operation manual.

### ⚠ CAUTION

- The above table shows the check frequency for standard condition.
- The check frequency may vary depending on the condition in which the machine is used.

### 11.2 Inspection And Maintenance Work Contents

#### 1. Daily maintenance

Carefully wipe off any mud, dirt or oil from each component.  
If oil leaks, retighten the joints and check again.

#### 2. Maintenance after every 50 hours of operation

Remove the fuel filter cup and clean the inside thoroughly. (Fig.10) Remove the spark plug and clean it. Then adjust the gap to 0.6 to 0.7 mm.





Fig.10

### 3. Replacing the lubrication oil

Remove the drain plug on the lower part of the machine body and drain the oil inside. Then add the specified amount of new oil.

Model	MTX-50	MTX-60	MTX-70	MTX-80
Capacity (liters)	0.35	0.65	0.82	0.82




### 4. Cleaning the air cleaner

Remove the upper air cleaner cover on the main body. Loosen and remove the 2 Phillips screws that hold the cover on the air cleaner assembly.

#### a. Primary element

**(clean every 80 to 100 hours)**



If the primary element is dirty, wash it with gasoline or lamp kerosene. Then, dip it in engine oil SAE10W-30 and wring it out. (Wring the element so that 25 to 30 cc of engine oil remains in the element.) (Fig.12)



#### b. Secondary element

**(clean every 100 to 150 hours)**

If the secondary element (Fig. 13) under the primary element is dirty, wash it with neutral detergent and dry it well. Then reuse it. (Fig.14)



### 5. Be sure to check the fuel line for damaged or looseness.

Replace the fuel line every 2 years, even if it does not show any abnormality.

### 6. Cleaning the machine body

If you want to clean the machine body using high-pressure steam, do not spray water directly into the air cleaner, carburetor, muffler, or top of the fuel tank. Otherwise engine problems may occur.

## 12. TROUBLE SHOOTING

### Engine

#### 1. Won't start

Fuel is present but the spark plug is not sparking.	Electricity is being supplied to the high voltage cable.	The gap in the spark plug tip is clogged. Carbon is stuck on the spark plug The spark plug has a short circuit due to faulty insulation. The gap in the spark plug is the wrong size.
	Electricity is not being supplied to the high voltage cable	The stop button switch has a short circuit. The ignition coil is broken.
Fuel and spark are both present.	Compression is good	The muffler is clogged with carbon. The wrong fuel was used. The air cleaner is clogged. The fuel is contaminated with water or dirt. The cylinder head gasket is blown or the head is not correctly tightened.
	Compression is low	The piston rings don't fit well. The cylinder is worn. The spark plug is not seated tightly. The valve seat is damaged.
Fuel is not being supplied to the carburetor.	No fuel in the fuel tank. Faulty fuel cock operation. The fuel filter is clogged. The air hole in the cap on the fuel tank is clogged. Air is trapped in the fuel line.	

#### 2. Faulty operation

Too little power	Good compression and no misfiring		Dirt in the air cleaner. Air trapped in the fuel line. Carbon has accumulated in the cylinder.
	Low compression (See "Compression in low" above)		
	Good compression but misfires		Faulty ignition coil. Dirt on the spark plug. Ignition coil shorts sometimes.
Engine overheats	Excessive accumulation of carbon in the combustion chamber. Clog exhaust port or muffler. Faulty spark plug.		
Smoke comes from the muffler	Black smoke		Choke lever wasn't returned to the open position.
	Blue smoke	Good compression	Blended oil (for 2-cycle engines) was used. Too much oil. Engine oil leaked into the air cleaner when the machine was laid down on the wrong side.
		Compression is low	Worn piston rings. The piston rings don't fit well.
	White smoke		Moisture in the gasoline. The air cleaner is wet.

(In the winter, the machine may emit white smoke for a while when first started in the morning. This is not abnormal.)

Engine speed fluctuates	Faulty governor adjustment. Faulty governor spring. Faulty fuel flow. Air being sucked into the fuel line.
-------------------------	---

*Mikasa*

MIKASA SANGYO CO., LTD.

1-4-3, Kanda-Sarugakucho, Chiyoda-ku, Tokyo, 101-0064, Japan

PRINTED IN JAPAN